



HOUNTING INSTRUCTIONS:
 BEFORE HOUNTING OF ROLLER BEARINGS(C17H7)
 TREAT THE BEARING SEAT OF THE AXLE BOX
 HOUSING WITH ASSY PASTE (ITEM6)
 COATING TO SPEC. 10040050/X

FORMER HENSCHL 3RD 667 - (L104000)

NOTE REFER ORIGINAL SKF DWG NO. 1140 050-4.

NO.	DATE	BY	CHKD	DESCRIPTION
1	1995-03-10
2	1995-03-10
3	1995-03-10
4	1995-03-10
5	1995-03-10
6	1995-03-10
7	1995-03-10
8	1995-03-10
9	1995-03-10
10	1995-03-10
11	1995-03-10
12	1995-03-10
13	1995-03-10
14	1995-03-10
15	1995-03-10
16	1995-03-10

ABB Transportation Pty Limited
 AXLE BOX COMPLETE WITH BLANK COVER
 LA011-0035