

Cable Connection chart of Auxiliary Cubicle HB2 for WAP7/WAG9/WAP5

Supposed to be Included in CLW Spec no. CLW/ES/3/0192

35 PIN /12 GRADE XK67S

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	2050	XK67S-1	52.6/1-A2
2	2.5	2050	XK67S-1	47.2A/2-3
3	1.5	2858	XK67S-2	89.2-B
4	1.5	2801B	XK67S-3	62.1/2-23
5	1.5	2850B	XK67S-4	53.1/2-24
6	1.5	2851B	XK67S-5	55.1/2-24
7	1.5	2852B	XK67S-6	56.1/2-24
8	1.5	2853B	XK67S-7	54.1/2-24
9	1.5	2855B	XK67S-8	59.1/2-24
10	1.5	2856B	XK67S-9	62.1/2-24
11	1.5	2857B	XK67S-10	63.1/2-24 (DELETED)
12	1.5	3037B	XK67S-11	47.2A/2-2+
13	1.5	2840B	XK67S-26	47.1/2-14
14*	1.5	2890B	XK67S-27	Link from A1 to 54.2/2-3
15*	1.5	2897	XK67S-28	54.2/2-4
16	2.5	5094	XK67S-29	52.4/1-13
17	2.5	5094	XK67S-30	52.4/2-13
18	2.5	2877A	XK67S-31	52.6/1-A1
19	2.5	2877B	XK67S-32	52.6/2-A1
20	2.5	2880A	XK67S-33	52.5/2-54
21	2.5	2880B	XK67S-34	52.5/1-54

7 PIN /12 GRADE XK67C:01

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	1218	XK67C:01-1	XB67A-1
2	6	1218	XK67C:01-2	XB67A-1
3	2.5	6501	XK67C:01-3	XK67C:02-3
4	2.5	6510	XK67C:01-4	XK67C:02-4
5	2.5	6503	XK67C:01-6	XK67C:02-6

7 PIN /12 GRADE XK67C:02

Sl. No.	Cable Cross	Cable no.	Connection From	Connection To
---------	-------------	-----------	-----------------	---------------

PREPARED BY

CHECKED BY

APPROVED BY

	Section			
1	6	1218	XK67C:02-1	XB67A-1
2	6	1200	XK67C:02-5	54.1/2-1
3	2.5	6501	XK67C:02-3	XK67C:01-3
4	2.5	6510	XK67C:02-4	XK67C:01-4
5	2.5	6503	XK67C:02-6	XK67C:01-6

4 PIN XK67P:01

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	6	1157B	XK67P:01-1	62.1/2-2
2	6	1158B	XK67P:01-2	62.1/2-4
3	6	1159B	XK67P:01-3	62.1/2-6

- *** 4 PIN XK67A:05**

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	1218	XK67A:05-1	XB67A-2
2	2.5	1201B	XK67A:05-2	54.1/2-2
3	2.5	1202B	XK67A:05-3	54.5/2-Q2 (For WAG 9 only)
3A	2.5	1202B	XK67A:05-3	XK67A-9 (For WAP 7 & 5 only)
3A	2.5	1202B	54.1/2-Q2	Lower panel TB (For WAP 7 & 5 only)

4 PIN XK67A:05

(Modified Connection for inverter fed MR Blower)

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	1201B	XK67A:05-1	54.1/2-2
2	2.5	1202B	XK67A:05-2	54.1/2-4
3	2.5	1204B	XK67A:05-3	54.1/2-6

*** 4 PIN XK67A:06**

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	1218	XK67A:06-1	XB67A-2
2	2.5	1211B	XK67A:06-2	56.1/2-2

4 PIN XK67A:06

(Modified Connection for inverter fed ScMR Blower)

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	1211B	XK67A:06-1	56.1/2-2
2	2.5	1212B	XK67A:06-2	56.1/2-4
3	2.5	1213B	XK67A:06-3	56.1/2-6

4 PIN XK67AC:01 (CAB 1)

Sl. No.	Cable Cross Section	Cable no.		Connection To
1	2.5	1143A	XK67AC:01-1	DT SWITCH-2
2	2.5	1144A	XK67AC:01-2	DT SWITCH-6
3	2.5	1145A	XK67AC:01-3	DT SWITCH-10

4 PIN XK67AC:02 (CAB 2)

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	1143B	XK67AC:02-1	DT SWITCH-4
2	2.5	1144B	XK67AC:02-2	DT SWITCH-8
3	2.5	1145B	XK67AC:02-3	DT SWITCH-12

4 PIN XK67A:02

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	1137B	XK67A:02-1	55.1/2-2
2	2.5	1138B	XK67A:02-2	55.1/2-4
3	2.5	1139B	XK67A:02-3	55.1/2-6

4 PIN XK67D

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	25	1131	XK67D-1	XH67A-4
2	25	1132	XK67D-2	XH67A-5

PREPARED BY

CHECKED BY

APPROVED BY

3	25	1133	XK67D-3	XH67A-6
---	----	------	---------	---------

4 PIN XK67B

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	25	1121B	XK67B-1	XH67A-1
2	25	1122B	XK67B-2	XH67A-2
3	25	1123B	XK67B-3	XH67A-3

4 PIN XK67E:01

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	50	1121B	XK67E:01-1	XH67A-1
2	50	1122B	XK67E:01-2	XH67A-2
3	50	1123B	XK67E:01-3	XH67A-3

4 PIN XK67E:02

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	50	1131	XK67E:02-1	XH67A-4
2	50	1132	XK67E:02-2	XH67A-5
3	50	1133	XK67E:02-3	XH67A-6

52.7.CONTACTOR

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	2877B	52.7-A1	52.7A-2+
2	2.5	2050	52.7-A2	52.7A-4-
3	2.5	1140B	52.7-1	64.1/2-2
4	2.5	1143B	52.7-2	DT SWITCH-1
5	2.5	1141B	52.7-3	64.1/2-4
6	2.5	1144B	52.7-4	DT SWITFH-5
7	2.5	1142B	52.7-5	64.1/2-6
8	2.5	1145B	52.7-6	DT SWITCH-9

52.7A SNUBBER CIRCUIT

Sl. No.	Cable	Cable no.	Connection From	Connection To
---------	-------	-----------	-----------------	---------------

	Cross Section			
1	2.5	2877B	52.7A-1+	52.6/2-2
2	2.5	2877B	52.7A-2+	52.7-A1
3	2.5	2050	52.7A-3-	47.2A/2-4
4	2.5	2050	52.7A-4-	52.7-A2

47.2/2 , CONTACTOR

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	1.5	3037A	47.2/2-A1	47.2A/2-1+
2	1.5	2050	47.2/2-A2	47.2A/2-4
3	10	1131	47.2/2-1	XH67A-4
4	10	1141B	47.2/2-2	47.1/2-1
5	10	1132	47.2/2-3	XH67A-5
6	10	1142B	47.2/2-4	47.1/2-3
7	10	1133	47.2/2-5	XH67A-6
8	10	1143B	47.2/2-6	47.1/2-5

47.2A/2 , SNUBBER CIRCUIT

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	1.5	3037A	47.2A/2-1+	47.2/2-A1
2	1.5	3037A	47.2A/2-2+	XK67S-11
3*	2.5	2050	47.2A/2-3	54.2/2-A2
4	2.5	2050	47.2A/2-3	XK67S-1
5	2.5	2050	47.2A/2-4	52.7A-3-
6	1.5	2050	47.2A/2-4	47.2/2-A2

52.6/1, AUX. CONTACTOR, 80A

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	2877A	52.6/1-A1	XK67S-31
2	2.5	2050	52.6/1-A2	52.6/2-A2
3	2.5	2050	52.6/1-A2	XK67S-1
4	1.5	5094	52.6/1-1+	52.4/1-13
5	2.5	2877A	52.6/1-2+	XB67A-3

52.6/2, AUX. CONTACTOR 80A

PREPARED BY

CHECKED BY

APPROVED BY

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	2877B	52.6/2-A1	XK67S-32
2	2.5	2050	52.6/2-A2	XB67A-5
3	2.5	2050	52.6/2-A2	52.6/1-A2
4	1.5	5094	52.6/2-1+	52.4/2-13
5	2.5	2877B	52.6/2-2	XB67A-4
6	2.5	2877B	52.6/2-2	52.7A-1+

89.2, EARTH FAULT RELAY

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	1.5	1105	89.2-U	90.3/1-Q2 (For WAG 9 only)
1A	1.5	1105	89.2U	XB67A-10 (For WAP 7 & 5 only)
1A	1.5	1105	90.3/1-Q2	Lower panel TB (For WAP 7 & 5 only)
2	0	0	89.2-V	MASSE-M
3	1.5	2801B	89.2-A	47.1/2-13
4	1.5	2801B	89.2-A	56.1/2-23
5	1.5	2858	89.2-B	XK67S-2

* 54.2/2, CONTACTOR WITH TIME DELAY MODULE

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	1.5	2890B	54.2/2-A1 TO 3	XK67S-27
2	1.5	2890B	54.2/2-3	54.2/2-A1 (Timer)
3	2.5	1201B	54.2/2-R1	XB67A-7
4	2.5	1204B	54.2/2-R2	54.8/2-Q1 (For WAG 9 only)
4A	2.5	1204B	54.2/2-R2	XB67-8 (For WAP 7 & 5 only)
4A	2.5	1204B	54.8/2-Q1	Lower panel TB (For WAP 7 & 5 only)
5	2.5	1201B	54.2/2-R3	XB67A-7
6	2.5	1204B	54.2/2-R4	54.8/2-Q1 (For WAG9 only)
6A	2.5	1204B	54.2/2-R4	XB67A-8 (For WAP 7 & 5 only)
7	1.5	2897	54.2/2-4	XK67S-28

8	1.5	2050	54.2/2-A2	54.2/2-A2 (Timer)
9	1.5	2890	54.2/2-A1	54.2/2-16 (Timer)

62.1/2, CIRCUIT BRERAKER, 16A, 3 POLE

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	10	1134	62.1/2-1	XH67A-7
2	6	1157B	62.1/2-2	XK67P:01-1
3	10	1135	62.1/2-3	XH67A-8
4	6	1158B	62.1/2-4	XK67P:01-2
5	10	1136	62.1/2-5	XH67A-9
6	6	1159B	62.1/2-6	XK67P:01-3
7	1.5	2801B	62.1/2-23	XK67S-3
8	1.5	2801B	62.1/2-23	63.1/2-23 (DELETED)
9	1.5	2856B	62.1/2-24	XK67S-9

47.1/2, CIRCUIT BREAKER, 40A, 3 POLE

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	10	1141B	47.1/2-1	47.2/2-2
2	10	1187B	47.1/2-2	XB67A:04-1
3	10	1142B	47.1/2-3	47.2/2-4
4	10	1188B	47.1/2-4	XB67A:04-2
5	10	1143B	47.1/2-5	47.2/2-6
6	10	1189B	47.1/2-6	XB67A:04-3
7	1.5	2801B	47.1/2-13	89.2-A
8	1.5	2840B	47.1/2-14	XK67S-26

53.1/2, CIRCUIT BREAKER, 63A, 3 POLE

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	10	1121B	53.1/2-1	XH67A-1
2	10	1127A	53.1/2-2	XB67A:01-1
3	10	1122B	53.1/2-3	XH67A-2
4	10	1128A	53.1/2-4	XB67A:01-2
5	10	1123B	53.1/2-5	XH67A-3
6	10	1129A	53.1/2-6	XB67A:01-3
7	1.5	2801B	53.1/2-23	55.1/2-23
8	1.5	2801B	53.1/2-23	63.1/2-23 (DELETED)
9	1.5	2850B	53.1/2-24	XK67S-4

55.1/2, CIRCUIT BREAKER,10A, 3 POLE

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	10	1124	55.1/2-1	XB67U:02-1
2	2.5	1137B	55.1/2-2	XK67A:02-1
3	10	1125	55.1/2-3	XB67U:02-2
4	2.5	1138B	55.1/2-4	XK67A:02-2
5	10	1126	55.1/2-5	XB67U:02-3
6	2.5	1139B	55.1/2-6	XK67A:02-3
7	1.5	2801B	55.1/2-23	59.1/2-23
8	1.5	2801B	55.1/2-23	53.1/2-23
9	1.5	2851B	55.1/2-24	XK67S-5

59.1/2, CIRCUIT BREAKER,10A, 3 POLE

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	16	1121A	59.1/2-1	XB67U:01-1
2	16	1147B	59.1/2-2	XB67A:03-1
3	16	1122A	59.1/2-3	XB67U:01-2
4	16	1148B	59.1/2-4	XB67A:03-2
5	16	1123A	59.1/2-5	XB67U:01-3
6	16	1149B	59.1/2-6	XB67A:03-3
7	1.5	2801B	59.1/2-23	54.1/2-23
8	1.5	2801B	59.1/2-23	55.1/2-23
9	1.5	2855B	59.1/2-24	XK67S-8

*** 54.1/2, CIRCUIT BREAKER, 20A, 1 POLE**

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	6	1200	54.1/2-1	56.1/2-1
2	6	1200	54.1/2-1	XK67C:02-5
3	2.5	1201B	54.1/2-2	XK67A:05-2
4	2.5	1201B	54.1/2-2	54.5/2-Q1 (For WAG 9 only)
4A	2.5	1201B	54.1/2-2	XB67A-9 (For WAP 7 & 5 only)
4A	2.5	1201B	54.5/2-Q1	Lower panel TB (For WAP 7 & 5 only)
5	1.5	2801B	54.1/2-23	56.1/2-23

PREPARED BY

CHECKED BY

APPROVED BY

6	1.5	2801B	54.1/2-23	59.1/2-23
7	1.5	2853B	54.1/2-24	XK67S-7

54.1/2, CIRCUIT BREAKER, 10A, 3 POLE

(Modified Connection for inverter fed MR Blower)

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	6	1121B	54.1/2-2	XH67A-1
2	6	1122B	54.1/2-4	XH67A-2
3	6	1123B	54.1/2-6	XH67A3
4	2.5	1121A	54.1/2-1	56.1/2-1
5	2.5	1122A	54.1/2-3	56.1/2-3
6	2.5	1123A	54.1/2-5	56.1/2-5
7	1.5	2801A	54.1/2-23	59.1/2-23
8	1.5	2801A	54.1/2-23	56.1/2-23
9	1.5	2853B	54.1/2-24	XK67S-7

***56.1, CIRCUIT BREAKER, 10A, 1 POLE**

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	6	1200	56.1/2-1	54.1/2-1
2	2.5	1211B	56.1/2-2	XK67A:06-2
3	1.5	2801B	56.1/2-23	54.1/2-23
4	1.5	2801B	56.1/2-23	89.2-A
5	1.5	2852B	56.1/2-24	XK67S-6

56.1, CIRCUIT BREAKER, 10A, 3 POLE

(Modified Connection for inverter fed ScMR Blower)

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	1121A	56.1/2-1	54.1/2-1
2	2.5	1122A	56.1/2-3	54.1/2-3
3	2.5	1123A	56.1/2-5	54.1/2-5
3	1.5	2801A	56.1/2-23	54.1/2-23
4	1.5	2852B	56.1/2-24	XK67S-6

64.1, CIRCUIT BREAKER, 10A, 3 POLE

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	1121B	64.1-1	52.5/1-1
2	2.5	1140B	64.1-2	52.7-1
3	2.5	1122B	64.1-3	52.5/1-3
4	2.5	1141B	64.1-4	52.7-3
5	2.5	1123B	64.1-5	52.5/1-5
6	2.5	1142B	64.1-6	52.7-5

LOOSE CONNECTION (DT SWITCH)

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	1143B	DT SWITCH-1	52.7-2
2	2.5	1143A	DT SWITCH-2	XK67AC:01-1
3	2.5	1143B	DT SWITCH-4	XK67AC:02-1
4	2.5	1144B	DT SWITCH-5	52.7-4
5	2.5	1144A	DT SWITCH-6	XK67AC:01-2
6	2.5	1144B	DT SWITCH-8	XK67AC:02-2
7	2.5	1145B	DT SWITCH-9	52.7-6
8	2.5	1145A	DT SWITCH-10	XK67AC:01-3
9	2.5	1145B	DT SWITCH-12	XK67AC:02-3

52.4/1, CONTACTOR

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	1.5	2877A	52.4/1-A1	52.4A/1-1+
2	2.5	2050	52.4/1-A2	52.4A/1-4
3	16	1121A	52.4/1-1	XB67U:01-1
4	16	1124	52.4/1-2	XB67U:02-1
5	16	1122A	52.4/1-3	XB67U:01-2
6	16	1125	52.4/1-4	XB67U:02-2
7	16	1123A	52.4/1-5	XB67U:01-3
8	16	1126	52.4/1-6	XB67U:02-3
9	2.5	5094	52.4/1-13	XK67S-29
10	1.5	5094	52.4/1-13	52.6/1-1+
11	1.5	2879A	52.4/1-14	52.5/2-53

52.4A/1, SNUBBER CIRCUIT

Sl. No.	Cable	Cable no.	Connection From	Connection To
---------	-------	-----------	-----------------	---------------

PREPARED BY

CHECKED BY

APPROVED BY

	Cross Section			
1	1.5	2877A	52.4A/1-1+	52.4/1-A1
2	2.5	2877A	52.4A/1-2+	XB67A-3
3	2.5	2050	52.4A/1-3	XB67A-5
4	2.5	2050	52.4A/1-4	52.4/1-A2

52.4/2, CONTACTOR

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	1.5	2877B	52.4/2-A1	52.4A/2-1+
2	2.5	2050	52.4/2-A2	XB67A-5
3	10	1131	52.4/2-1	52.5/2-1
4	10	1124	52.4/2-2	XB67U:02-1
5	10	1132	52.4/2-3	52.5/2-3
6	10	1125	52.4/2-4	XB67U:02-2
7	10	1133	52.4/2-5	52.5/2-5
8	10	1126	52.4/2-6	XB67U:02-3
9	2.5	5094	52.4/2-13	XK67S-30
10	1.5	5094	52.4/2-13	52.6/2-1+
11	1.5	2879B	52.4/2-14	52.5/1-53

52.4A/2, SNUBBER

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	1.5	2877B	52.4A/2-1+	52.4/2-A1
2	2.5	2877B	52.4A/2-2	XB67A-4
3	2.5	2050	52.4A/2-3	XB67A-5
4	2.5	2050	52.4A/2-4	52.4/2-A2

52.5/1, CONTACTOR

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	1.5	2877B	52.5/1-A1	XB67A-4
2	1.5	2050	52.5/1-A2	XB67A-5
3	25	1121B	52.5/1-1	XH67A-1
4	2.5	1121B	52.5/1-1	64.1-1
5	25	1134	52.5/1-2	52.5/2-2
6	25	1134	52.5/1-2	XH67A-7
7	25	1122B	52.5/1-3	XH67A-2
8	2.5	1122B	52.5/1-3	64.1-3
9	25	1135	52.5/1-4	52.5/2-4

PREPARED BY

CHECKED BY

APPROVED BY

10	25	1135	52.5/1-4	XH67A-8
11	25	1123B	52.5/1-5	XH67A-3
12	2.5	1123B	52.5/1-5	64.1-5
13	25	1136	52.5/1-6	52.5/2-6
14	25	1136	52.5/1-6	XH67A-9
15	1.5	2879B	52.5/1-53	52.4/2-14
16	2.5	2880B	52.5/1-54	XK67S-34

52.5/2, CONTACTOR

Sl. No	Cable Cross Section	Cable no.	Connection From	Connection To
1	1.5	2877A	52.5/2-A1	XB67A-3
2	1.5	2050	52.5/2-A2	XB67A-5
3	25	1131	52.5/2-1	XH67A-4
4	10	1131	52.5/2-1	52.4/2-1
5	25	1134	52.5/2-2	52.5/1-2
6	25	1132	52.5/2-3	XH67A-5
7	10	1132	52.5/2-3	52.4/2-3
8	25	1135	52.5/2-4	52.5/1-4
9	25	1133	52.5/2-5	XH67A-6
10	10	1133	52.5/2-5	52.4/2-5
11	25	1136	52.5/2-6	52.5/1-6
12	1.5	2879A	52.5/2-53	52.4/1-14
13	2.5	2880A	52.5/2-54	XK67S-33

*** 54.5/2, CAPACITOR**

Sl. No	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	1201B	54.5/2-Q1	XB67A-7
2	2.5	1202B	54.5/2-Q2	XK67A:05-3 (For WAG 9 only)
3	2.5	1202B	54.5/2-Q2	54.8/2-Q2

*** 54.8/2, CAPACITOR**

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	1204B	54.8/2-Q1	54.2/2-R2 (For WAG 9 only)
2	2.5	1204B	54.8/2-Q1	54.2/2-R4 (For WAG 9 only)

PREPARED BY

CHECKED BY

APPROVED BY

3	2.5	1202B	54.8/2-Q2	54.5/2-Q2
---	-----	-------	-----------	-----------

90.3/1, RESISTOR

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	1.5	1103	90.3/1-Q1	S1103.1-Q1
2	1.5	1105	90.3/1-Q2	89.2-U (For WAG 9 only)
3	1.5	1105	90.3/1-Q2	90.3/2-Q1

90.3/2, RESISTOR

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	1.5	1105	90.3/2-Q1	90.3/1-Q2
2	1.5	1117	90.3/2-Q2	S1117.1-Q1

Bus Bar-1

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	2.5	1103	S1103.1-Q1	XF67A-1
2	1.5	1103	S1103.1-Q1	90.3/1-Q1

Bus Bar-2

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	1.5	1117	S1117.1-Q1	90.3/2-Q2
2	2.5	1117	S1117.1-Q2	XF67A-6

XH67A (TB TO TB)

Sl. No.	Cable Cross Section	Cable no.	Connection From	Connection To
1	10	1134	XB67U:03-1	XH67A-7
2	10	1135	XB67U:03-2	XH67A-8
3	10	1136	XB67U:03-3	XH67A-9

* In order to Drive MR Blower and ScMR Blower by three phase supply from BUR2 the connections should be treated as deleted.

DRAFT

PREPARED BY

CHECKED BY

APPROVED BY